How to use a
HITACHI wall mount control

Cool/heat display

Temperature display

Fan display

On/off button

Arrow buttons

▲ : Up
▼ : Down
◄ : Left
► : Right

General Information

→ On very cold mornings, it can take up to 25 minutes for the unit to defrost and begin blowing warm air after it's turned on.

→ The thermostat will make the unit turn off and on to keep the room at the selected temperature.

Turning the unit on and off

1. Turn on the unit by pressing the on/off button once (a light will indicate the unit is on).

2. Once on, to turn off, press the on/off button once.

homes victoria

VICTORIA State Government

How to select the cooling or heating mode

1. Press the ◄ **left and** ► **right arrows** until **Mode** setting is selected.

2. Press the ▲ **up and** ▼ **down arrows** until either **Cool** or **Heat** is selected (ignore the other options).

Select setting

→

MODE SPEED SWING TEMP
HEAT ► AUTO **23** °C
►SPEED ➕ADJ

→

Select COOL or HEAT

How to change the temperature

1. Press the ◄ **left and** ► **right arrows** until **Temperature** setting is selected.

2. Press the ▲ **up and** ▼ **down arrows** to select the desired temperature.

Select setting

→

MODE SPEED TEMP
AUTO AUTO **25** °C
◄SPEED ➕ADJ

→

Select temperature

* *A comfortable temperature is typically between 18–24 degrees.*

How to select the fan speed

1. Press the ◄ **left and** ► **right arrows** until **Fan speed** setting is selected.

2. Press the ▲ **up and** ▼ **down arrows** to select the desired fan speed.

Select setting

→

MODE SPEED TEMP
AUTO AUTO **21** °C
◄MODE ►TEMP ➕ADJ

→

Select fan speed

Find out more: You can access the full instruction manual for the wall mount control at the following web site:

https://tinyurl.com/ycxnypw4