


# How to use a MITSUBISHI ELECTRIC wall mount control



## General information


- On very cold mornings, it can take up to 25 minutes for the unit to defrost and begin blowing warm air after it's turned on.
- The thermostat will make the unit turn off and on to keep the room at the selected temperature.

## Turning the unit on and off

1. Turn on the unit by pressing the on/off button once (a green light will indicate the unit is on).
2. Once on, to turn off, press the on/off button once.


## How to select the cooling or heating mode

1. To select the **Mode** setting, press the **F1** button below the display.
2. Press the **F1** button to cycle between the modes until either **Heat** or **Cool** are selected (ignore the other options).



## How to change the temperature


1. To select the **Temperature** setting, press either the **F2** and **F3** button below the display.
2. Press the **F2** button to decrease the temperature or the **F3** button to increase the temperature.



\* A comfortable temperature is typically between 18–24 degrees.

## How to select the fan speed

1. To select the **Fan** setting, press the **F4** button below the display.
2. Press the **F4** button to cycle between the different fan speeds.



**Find out more:** You can access the full instruction manual for the wall mount control at the following web site:

<https://tinyurl.com/385hv6xc>

